



Nighteater

Spotting Scope 20-60x85

Instruction for Use

Congratulations on your purchase of a quality Nighteater spotting scope. It is a high-quality optical instrument for viewing birds, wildlife, sports events, or anything else you want to see more closely. It will provide many years of enjoyable viewing. Before using your spotting scope, we recommend that you read through the following instructions.

A. How to Mount

1. Take out the Scope unit and eyepiece from the package.
2. Take off the dustcap and insert the eyepiece to the eyepiece hole on the scope unit.
3. Grasp the scope firmly, turn the eyepiece clockwise until a click heard. This means the eyepiece has been locked into position.
4. Extend the tripod on a solid surface and make sure all screws have been tightened securely.

5. Mount the Spotting Scope to the quick shoe on the tripod panhead.

B. Sunshade hood

Your spotting scope features a sliding retractable lens shade. Normally the lens shade is kept retracted, but in circumstances where glare is a problem the lens shade can be extended to help comfortable viewing. This is useful for keeping unwanted light from reaching the objective lens and washing out the image.

C. Clamp Screw

Turn the Clamp Screw up, rotate the angled scope right or left to view the same sight at different viewing height, then fix it by turning the Clamp Screw down. This will be a great feature when viewing the objects with your family.

D. Eyecup adjustment

Twist-up eyecup can be rotated and stopped at a desired height. If you do not wear sun/eyeglasses, twist the eyecups up, and if you do, twist the eyecups down. This will bring your eyes closer to the lens thus providing improved field of view.

E. Power adjustment

Grasp the scope firmly, rotate the power ring on the eyepiece clockwise to have a higher magnification and counterclockwise to have a lower magnification.

F. Focusing

Turn the focus knob with your fingers until the object comes into sharp focus. Make sure that you are turning the focus knob and not turning the zoom eyepiece. Go a little bit beyond sharp focus until the image just starts to blur again, then reverse the rotation of the knob. This will for sure help you hit the exact focus point.

G. Adjustment of the Tripod

The tripods can be adjusted for height by releasing the levers on each leg until the legs extend to the desired length. Uneven surfaces are not a problem as the legs can be set individually. A vision bubble level guides you. The direction of the spotting scope can be quickly adjusted for rotation, and elevation using the three knobs.

H. Instruction for care

1. Always store your spotting scope in its case when not in use.
2. When wiping the lenses, use a soft lintless cloth.
3. To remove any remaining dirt or smudges, add one or two drops of Isopropyl alcohol to the cloth.
4. Store your spotting scope in a moisture-free area.

Caution:

Never disassemble the scope unit or eyepiece. Special tools and equipment are required for service and irreparable damage can result from untrained attempted service. Unauthorized service may also void the warranty.

Warning: Viewing the sun can cause permanent eye damage. Do not view the sun with this product or even with the naked eye.

www.nikkostirling.com