



Nighteater

Scope Aligner Instructions for use.

Warning

Please check your firearm is not loaded ! Your action should remain open at all times and the barrel should be pointed in a safe direction during the use of this Scope aligner.

Intended Use

This product is designed to allow firearms owners to save Valuable time and ammunition when sighting in their firearms when they have attached a new riflescope. This pre Zeroing of the firearm should be followed by proper range or field zeroing before the firearms used in the field.

Warning

Be sure to wear ear and eye protection whenever firing a firearm.

Instructions

Please follow the instructions supplied by your riflescope and mount maker for correctly mounting your riflescope. We assume this is done correctly and offer no guarantee regarding this. If you are uncertain, We highly recommend you consult a firearms expert or the retailer that you bought the products from.

Once the scope is mounted correctly you can use the Scope aligner to pre Zero your firearm.

1. Select the correct bore Arbor that matches your firearms barrel calibre . Each Arbor is clearly marked. Slide the Arbor into the scope aligner with the notched section first. Rotate the Arbor until the notched section is facing to the screw that should be hand tightened to secure the Arbor to the Scope aligner.
2. Insert the Arbor into the muzzle of the firearm. If it does not fit easily recheck you have the correct Arbor.
3. Rotate the aligner in the barrel to locate it in a vertical position in line with the riflescope.
4. Look through the scope and you should see the Sighting grid clearly. If the grid is not clear you may need to adjust the focus of the scope, Follow the instructions supplied with your scope to adjust the image.
5. Remove the elevation and windage adjustment caps. Make the adjustment of the windage and elevation according the scopes instruction manual to bring the reticle of the scope to the centre of the grid. Once this is achieved you should replace the adjustment covers and remove the Aligner from the barrel.
6. Your firearm is now pre Zeroed!